

Bench Seat installation instructions

- 1. Our seat is designed to be installed after you have installed the surround in your shower..**
- 2. You will first need to build a wood frame for your bench seat. The size of the skirt panels will determine the size of your frame.**
- 3. Secure the frame by drilling through the wood and shower surround making sure you line the holes up with the studs behind your wall. Anchor by using stainless steel wood screws. We recommend using 100% mildew resistant silicone to place a seal behind and under the frame as well as the screws.**
- 4. Install your skirt panels using construction adhesive such as PL Premium Polyurethane Adhesive. Be sure to install panels so the finished edge is in the proper location.**
- 5. Place a bead of the construction adhesive around the top of the frame and place the seat on the frame with the over hang being even.**
- 6. Seal all seams with 100% mildew resistant silicone.**
- 7. Enjoy your new cast polymer bench seat! With proper installation and care your seat will provide you with many years of service.**

**AL-CO PRODUCTS INC.
485 SECOND STREET PO BOX 74
LATTY, OHIO 45855
PHONE-1-800-686-2489
FAX -419-399-4702**